


1. IP Phone Installation

EQ-X210 supports POE supply and power adapter(DC5V2A).



2. If connect to a POE Switch with DHCP, go to Menu>Status to check the IP.




Without DHCP, unable to get a IP. We should set a IP manually. Go to **Menu>Advanced(password:123)>Network>Network>IPv4**, change the Network mode to Static, fill in your IP.




3. Enter the IP on the browser(recommend Google Chrome)

Both default username and password are admin




4. Network Setting.



5. SIP Setting

Line>SIP. The picture below only for reference, fill in your actual info please. Then click on supply to save.




It can also be configured on the phone

Go to Menu>Advanced(Password:123)>Accounts,select a SIP to configure.



Codecs Settings

Audio Codecs. If you do not use such G.722 codecs etc. We recommend only enable G.711U&G.711A.




6. Function Key Setting.


Function Key allows you call someone with a single click rather than dialing their extension number.

It can also be used to set an IP address, press the function key to make an IP direct call.


The EQ-X210 has a **total of 96 function keys**, which are divided into three pages. Each page supports 32 function keys.



Function Key in page 1



Function Key in page 2



Function Key in page 3